

To install check valve:

- Press fit into place with brass weight facing up.
- If fit is not snug, apply a small bead of G.E. silicone adhesive sealant to secure in place.
- Make sure check valve moves freely after installation.