HAYVARD[®]

OmniPL[™] Retrofit Installation Quick Start Guide

Pre-Installation Checklist

- Networked ColorLogic lights must be set in "Standalone" mode or they will fail to operate after the upgrade.
- All equipment settings and schedules will be lost after the upgrade.
- This upgrade will convert the old control to the Omni family of products and will require Omni specific accessories. Old remote controls. AQL2-BASE antennas and AQL-CHEM Sense and Dispense will no longer be compatible after the upgrade.
- For systems using a Hayward Ecostar VSP running firmware version less than R3.0.5 (pumps built before 2014), a Hayward SPX3400LCD display must be purchased and installed on the EcoStar pump if vari-able speed operation is desired with the Omni automation control. If single speed control is desired, no changes are necessary.

ECOMMAND UPGRADE: Requires GLXS3PLXFMR purchased separately.

- Power is removed to all equipment in the system.
- All safety precautions have been read in the Installation manual.
- All of the necessary tools and mounting hardware have been gathered (drill, drill bits, Phillips & flathead screwdrivers, level, wire cutters/strippers, mounting anchors and fasteners).
- The Controller will be mounted a maximum of 15' from the OmniPL and will be mounted a minimum of 6' horizontal distance from the pool or spa. \square

Record Current Configuration and Wiring 1

Set ColorLogic Network lights into standalone mode before proceeding! All settings will be lost after upgrading. Before starting the installation, record all of the current settings and connections using the worksheets in the Installation manual. If there are accessories being used (ColorLogic lights, AQL-CHEM Sense and Dispense, etc.), you may have additional settings beyond what is covered in the worksheets. A Connection Table is provided to record all connected equipment. All of this information will be used to configure the new OmniPL and return your system to its original function.



2

With power disconnected to the control remove the door by opening, then lifting up and off of the hindes. Remove the deadfront panel, this will not be reused. Remove the keypad by pulling straight out (away from the mainboard) and disconnecting cable. Record the location of all wiring connections by taking a photo or writing them down.

Remove Wiring from Old Mainboard 3

After taking a photo, start removing the wiring from the old printed circuit board (PCB). For ProLogic and AquaPlus, the green terminal blocks can be lifted off of the old board without the need to remove individual wires. These terminal blocks will connect to the new board in exactly the same manner. WARNING: AQUALOGIC AND ECOM-MAND - DO NOT REUSE TERMINAL BLOCK. To avoid damage, remove the individual wires and attach to the OmniPL mainboard's terminal block. Many of the connections from the old PCB will connect to the new OmniPL mainboard at the same locations but refer to the labeling on the new board to avoid damage. Some high voltage wiring will be removed and not used. Refer to the callouts for each of the connections shown below in the diagram.



Replace the Old PCB with the OmniPL PCB

Depending on your model, use either a screwdriver or 5/16 nut driver to loosen or remove the fasteners securing the old PCB to the enclosure. Slide the board up to remove. Place the new OmniPL PCB in the same location and secure with the original fasteners.



WWW.HAYWARD.COM 908-355-7995

Access Mainboard



Turn Over

C HAYWARD[®]

OmniPL[™] Retrofit Installation Quick Start Guide

Mount Controller 5

The OmniPL Controller has a 15 ft cord which must plug into the OmniPL mainboard. When considering a suitable mounting location, refer to the Pre-Installation Checklist on the front of this Quick Start Guide and mount in a location that is convenient for viewing and changing settings. Allow enough clearance above the enclosure so that the flip door can open fully.

A mounting template is provided in the Installation manual. To install, screw two appropriate fasteners into the mounting surface at the desired location as shown. Tighten until the bottom of the screw heads are 1/8" off the mounting surface then hang the Controller firmly on the screws.



Start Up, Configuration and Registration 7

With all connections complete, tuck back all the wiring to prepare for the deadfront installation. Locate the new deadfront and knockout all appropriate breaker locations. Install the new deadfront panel and reattach the door. Turn on power to the OmniPL. The OmniPL will power on and prompt you to begin configuration (see below). The Configuration Wizard will ask you general questions relating to your pool/spa and specific questions about connected pool equipment. Configuring the OmniPL requires knowledge of all of the connected pool equipment. Refer to your worksheets and Connection Table from Step 1 while configuring the OmniPL.





Find your MSP ID

After configuration, the OmniPL can be controlled from your mobile device. You must first create an account and register your OmniPL using Hayward's "Omni-Logic" app available in your device's app store. During registration, you'll be asked for the OmniPL's MSP ID to link to your account. To find the MSP ID, follow the steps below using the touchscreen Controller.







Create an OmniLogic Account using OmniLogic App on your mobile device

Download the "OmniLogic" app from your mobile app store. Launch the app and select "Don't have an account?" at the bottom of the screen. Follow the prompts until your account is setup.

After setup, select "Add New Site" to link the OmniPL to your account. Input your MSP ID and fill out the remaining information.

With the OmniPL now linked to your account, you can control your pool remotely from any PC, laptop, or mobile device. For computers, go to haywardomnilogic.com and log in to your account. For mobile devices, download the OmniLogic app and then log in to your account.



Install Wiring to OmniPL PCB 6

Connect the wiring from the old PCB to the new OmniPL PCB according to the wiring connection callouts below. For ProLogic and AquaPlus, the green terminal blocks can connect in the same locations as the old PCB. For AquaLogic and ECOMMAND, individual wires must be removed from the old terminal blocks and connected to the OmniPL's terminal blocks.



OmniPL Operation

For detailed information about operation (turning on equipment, setting schedules, changing heater settings, etc.), refer to the OmniPL Retrofit Kit Operation manual.

092779 RevB